
MODUM
for your safety



Inspection ladder

- You can only open the ladder form the bottom with a ruko lock.

Universal Ladder

- You can open the ladder from bottom with a ruko lock AND you can open the ladder from the top with a release pin.

Fire Escape Ladder

- You can only open the ladder from top or each level with a release pin.

* The correct length of the ladder should be the measure length (blue line on drawing) deducted the distance lentgh from the ground (0,4m)

Ruko lock



Ruko lock with wire



Releasepin



Further information:

Brian Petersen
+45 21667438
bp@modum.dk